


2800



•

•

•


•

•

2200 .

3000 .


2800




1			2801	
2			2802	
3			2803 2804 2805 2806 2807	
4	28		2808	
5			2809 2810	
6			2811 2812	

7			2813	
8			2011 2012	
9			2816	
10				
11	ASTRA LT-28		2817	

## 2800




### Стеновой монтаж




А Прямая намотка  
Б Обратная намотка

### Потолочный монтаж



## Somfy Astra LT-28

( )	0,7
/	34
	27
	38
	24
	8
( )	380
( )	100
	40
(°)	-10° + 60°
	IP 44



1			2801
2			2802
3	-	.	2804 2805 2806 2807
4		.	2810
5	.		2812
6		.	2012
7	ASTRALT-28		2817



Telis 1RTS  
( )

Pure	9011
Silver	9012
Lounge	9013
Patio	9014




Telis 4RTS  
( )

Pure	9041
Silver	9042
Lounge	9043
Patio	9044




Telis Composio  
RTS  
( 20- )

Silver	9045
Lounge	9046




Centralis RTS  
( )

9002




RTS 25 DC  
2-

9026




odul DC RTS  
2-

9030




Chronis RTS L  
( )

9007



Chronis RTS  
( )

9003



Power 2,5 DC RTS


5-

9021

Power 2,5 DC

5-


9022



UPS-10

1-


9020



GPS - 30

3-


9008



GPS - 100

10-

9009



GPS 1020


10-  
IR3.

9010


- ( )




IRS 300	9023
3-	




IRT 803	9024
8 -	



IRT 103	9025
1 -	




IR3	9027
-	
GPS 1020.	




2- (24 )	9006
6-	

## Управление кнопкой



## Радиоуправление



## ИК-управление

